



CFC2


Place this manual with personnal responsible for maintenance of this valve



INSTALLATION



OPERATION



MAINTENANCE







Float Control For Closed Tanks



- Accurate Liquid Level Control
- Fully Hydraulic Operation
- Simple Design, Easy Maintenance
- No Lubrication Necessary
- No Gears, No Mechanical Linkage Between Valve and Control

The Cla-Val Model CFC2 Float Control is a float-actuated, multiport pilot control which provides non-modulating, two-position, onoff operation. It is used primarily to operate remotely located Cla-Val Valves requiring three-way or four-way pilot valve operation. Designed for use in closed tanks, this control operates on a minimum level change of approximately one inch. Maximum level change of five and one-half inches is needed for full capacity.

Note: We recommend protecting the control tubing and valve from freezing temperatures.

Specifications

Control Piping

Connections

Reservoir Connections ½" NPT

Pressure Rating 0-150 psi

Temperature

Rating

Water: to 180°F.

Materials

In contact with operating fluid:

Brass, Stainless Steel, Monel, with

Buna-N® Seals Float chamber: Cast Iron Pilot valve housing:

Bronze

Materials in contact with operating fluid: Brass, Stainless Steel, Monel with Buna-N® Seals

Float ball: Stainless Steel Float arm: Brass

Other material available:

Cast steel or aluminum chamber and pilot valve housing. All stainless steel

Level Differential Approximately 1" minimum required to


change pilot valve operation. 5 \% " required to develop full capacity.

Operating Fluids Clean liquids or gases compatible with

specified materials.

Shipping Weight 12 lbs.

Dimensions (In Inches)



Reservoir Connection

1" NPT (Typ. Both Ends 2 Places)



Installation Data

The float control is mounted at the high water level in the tank. The remote Cla-Val valve is installed in the line leading to the tank and is connected to the float control pilot by tubing. (Min. %" for valves 6" and smaller, %" or larger for valves 8" or larger.)

When line pressure is used to operate the valve, tubing connections are made from the float control pilot to the valve cover, and also to the inlet side of the valve. An X46 Flow Clean Strainer must be installed in the inlet side of the valve. The control may be installed at any elevation above the valve, providing that the flowing line pressure in psi is equal to, or


greater than, the vertical distance in feet between the valve and the float control.

An independent source of air or water may be used to operate the valve. The pressure from this independent source must constantly be equal to or greater than pressure at the valve inlet. The independent source is connected to the float control pilot in place of the supply line connected to the inlet side of the valve. If the Model 100-01 under the control of the CFC2 is 8" or larger, auxiliary Hytrol valves may be required. Consult factory for details.


Note: We recommend protecting the control tubing and valve from freezing temperatures.

X46 Flow Clean Strainer

For Controlling Hytrol Valve




Float Up Closes Valve



Float Down Closes Valve

When Ordering, Please Specify

- 1. Catalog No. CFC2-C1
- Size and Type of Valve to be Controlled.
- 3. Materials if different from standard
- Specify Gravity of Fluid if other than Water.




For Controlling Powertrol Valves


Float Up Closes Valve

DOWN

Float Up Opens Valve


CLOSED





For Controlling Two Valves Simultaneously

OPEN





CLA-VAL

PO Box 1325 Newport Beach CA 92659-0325 Phone: 949-722-4800 • Fax: 949-548-5441

CLA-VAL CANADA

4687 Christie Drive Beamsville, Ontario Canada LOR 1B4

Phone: 905-563-4963
Fax: 905-563-4040

«COPYRIGHT CLA-VAL 2007 Printed in USA
Specifications subject to change without notice.

ax. 545 546 54

CLA-VAL EUROPE Chemin dés Mesanges 1 CH-1032 Romanel/ Lausanne, Switzerland

Phone: 41-21-643-15-55 Fax: 41-21-643-15-50


www.cla-val.com

Represented By:



-MODEL - CFC2

Float Chamber Control



Common Parts:

Description	Material	
Float Ball	S.S.	
*Gasket	Neoprene	
Cap Screws	Steel Cad.	
3/8-16 x 7/8	Plated	


NOTE: SEE OTHER SIDE FOR EXPLORED PILOT AND HOUSING ASSEMBLY.

CATALOG NO.	BODY	PILOT & HOUSING	PIPE NIPPLE
OATALOG NO.		ASS'Y	1/4 X 2"
	MATERIAL	MATERIAL	MATERIAL
CFC2-A1	Iron	Bronze with S.S.	Bronze 67586-03
CFC2-A2	Iron	Bronze with S.S.	Bronze 67586-03
CFC2-C1	Iron	Bronze with S.S.	Bronze 67586-03
CFC2-A1	Iron	Steel with S.S.	S.S. 67586-19
CFC2-C1	Iron	Steel with S.S.	S.S. 67586-19
CFC2-A1	Steel	Steel with S.S.	S.S. 67586-19
CFC2-A2	Steel	Steel with S.S.	S.S. 67586-19
CFC2-C1	Steel	Steel with S.S.	S.S. 67586-19



- Model - CFC2

Pilot & Housing Assembly For Float Chamber Control



PILOT & HOUSING ASSEMBIIES (BRONZE W/STAINLESS STEEL) C426-1 FOR CFC2-A1 OR CFC2-A2-3 C2035 FOR CFC2-A2 OR CFC2-B2-3

C2149H FOR CFC2-C1 OR CFC2-B2-4		
ITEM	DESCRIPTION	MATERIAL
1	Machine Screw, Rd. Hd.,	Brass
	6/32 x 1", 6 Required	
*2	Distributor for C426-1	S.S.
	Distributor for C-2035	S.S.
	Distributor for C-2149-1	S.S.
*3	Gasket	Buna-N®
*4	Disc Assembly	Brass
		Monel
*5	Spring	S.S.
6	Pin, Lock	S.S.
7	Stem Assembly	Brass - S.S.
*8	"O" Ring	Buna-N®
9	Washer	Brass
10	Washer, Thrust	Brass
11	Arm, Float	Brass
12	Housing	Bronze
		ı

PILOT & HOUSING ASSEMBIIES (BRONZE W/STAINLESS STEEL) C426-1 FOR CFC2-A1 OR CFC2-A2-3 C2035 FOR CFC2-A2 OR CFC2-B2-3 C2149-1 FOR CFC2-C1 OR CFC2-B2-4

DESCRIPTION	MATERIAL
Machine Screw, Rd. Hd.,	Steel Cad.
6/32 x 1", 6 Required	Plated
Distributor for C-8017	S.S.
Distributor for 32340	S.S.
Distributor for 30792	S.S.
Gasket	Buna-N®
Disc Assembly	S.S.
Spring	S.S.
Pin, Lock	S.S.
Stem Assembly	S.S.
"O" Ring	Buna-N®
Washer	S.S.
Washer, Thrust	S.S.
Arm, Float	S.S.
Housing	Steel
	Machine Screw, Rd. Hd., 6/32 x 1", 6 Required Distributor for C-8017 Distributor for 32340 Distributor for 30792 Gasket Disc Assembly Spring Pin, Lock Stem Assembly "O" Ring Washer Washer, Thrust Arm, Float